

# HINTS AND TIPS ON —SERVICE—

*For* **BSA** *and* **ARIEL** *Dealers*

Service Bulletin #65

August 19, 1959

## Service Bulletin

### Folding Foot Rests for the C-15 Scrambler Model

The English type rigid foot rests do not meet the A. M. A. rules for Competition and there is limited space for foot clearance at the kick starter crank.

It will be necessary to assemble Folding Foot Rests at the specified angle to conform to the A. M. A. rules and to provide additional Foot clearance for kicking over the engine.

#### Parts Required:

- 2 - 42-4845 Pillion foot rest
- 2 - 29-7583     "     "     "     rubber

#### Instructions:

1. Remove the rigid foot rests and brackets.
2. Cut the rigid foot rest pedal at the end of the straight section.
3. Cut the stud off the pillion foot rest anchor bolt.
4. Weld the remaining section of the pillion foot rest anchor bolts on the original foot rest bracket so that it will fold backwards at a 45 degree angle.
5. Re-assemble foot rest brackets and folding foot rests back on the machine.

BSA Incorporated

*Walt Brown*

Walt Brown  
Service Manager

**BSA** Incorporated, 639 Passaic Avenue, Nutley N. J.