

despatch to all dealers:

SERVICE BULLETIN NO. 291

December 2, 1968

FROM: Walter Brown, Service Manager

SUBJECT: Front brake cable route on "A" Models fitted with double leading shoe brake.

The picture below illustrates the proper route using the three cable guides in which the front brake cable must follow. Rubber grommet, Part #76-9325 is used on the fender brace to keep the cable from drifting.

